

# **\*\*NEW\*\* MAINS POWER OPTION ENABLED ON ALL 2017 MODELS!**

**MAINS POWERED OPTION NOW ENABLED**

2017 ChickenGuard © Standard, Premium and Extreme.



You are now able to use the **mains power** option on your ChickenGuard using **USB cable** (A to A) and **USB charger**.

## REQUIREMENTS (NOT INCLUDED)

### USB to USB Cable

Separately purchase a USB to USB (A to A) cable (not included).



### USB Mains Charger

Separately purchase a USB charger, like many mobile phone chargers (not included).



## INSTRUCTIONS

### STEP 1

Remove the front panel of the ChickenGuard.

### STEP 2

Remove the battery holder, and attach the battery connector like so:



### STEP 3

Re-attach the front panel of the ChickenGuard.

### STEP 4

There is a USB port on the under-side of all mains power enabled ChickenGuard door openers.

Simply plug in the USB to USB (A to A) cable from the ChickenGuard to the USB mains charger.



-----Thank You-----